

Fitting Instructions for Spring hinge

HINGE TESTED WITH INTUMESCENT PADS

STEP 1

Fit first hinge 250mm from top of the door.
Make sure adjustment hole is on the top.

STEP 2

Position bottom hinge 250mm from the bottom of the door.

STEP 3

Position third hinge in the middle of the door between the top and the bottom hinges.

STEP 4

Place alun key into locator hole at the top of the hinge barrel and crank round until the desired tension is reached. There are 6 tension positions

STEP 5

Place the pin into the hole. Make sure you push it all the way in

STEP 6

Repeat step 5 with the bottom hinge. Make sure you make tension the same as the top hinge by cranking round to the same tension hole

NB: Leave the middle hinge unsprung

